



# EU BROMPTON SMALL, MEDIUM & LARGE WALL SCONCES

## General Product Information



## Tools Required



## Safety Information

### CAUTION-RISK OF FIRE

This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

USE MINIMUM 90°C SUPPLY CONDUCTORS.





Turn off electrical current at the source before working with any lighting fixture or portable lamp. Install and use this product in adherence with local electrical codes and regulations.



### DISPOSAL

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.





## FIXTURE PARTS

- A. Anchors
- B. Mounting Plate
- C. Mounting Screws
- D. Ground Screw
- E. Fixture Base
- F. Terminal Block
- G. Integrated LED
- H. Knurled Nuts
- I. Shade

## INSTRUCTIONS

### I. Preparing the Fixture

1. Hold the fixture base and carefully pull the shade off.
2. Remove the mounting plate from the fixture base by unscrewing the knurled nuts.
3. Using an electric drill, install the anchors to the wall (ensure there's an available mains connection) as follows:
  - a) Place the mounting plate on the junction box to trace and mark the locations for the anchor holes. Ensure that they are leveled.
  - b) Use the electric drill to drill the marked holes.
  - c) Insert the anchors into the holes.
4. Using a screwdriver and the mounting screws, install the mounting plate to the anchors in the wall.

### II. Wiring the Fixture

1. Safety first! Locate the circuit breaker and switch it off to cut off the power supply to the relevant circuits to ensure there's no electricity running through the wiring.
2. In accordance with local electrical codes, connect the fixture ground wire (bare copper or silver wire) to suitable ground. This may be a green ground screw on the mounting plate or an earth wire (green, yellow, or bare).
3. Connect the following pairs of wires together using a terminal block to secure a connection:
  - a) Hot driver wire (brown) and hot power line wire (brown) from the source (hot to hot)
  - b) Neutral driver wire (blue) and neutral power line wire (blue) from the source (neutral to neutral)
4. Ensure that the terminal block is capped off.
5. Neatly tuck the driver and all the wires into the fixture base.

### III. Installing the Fixture

1. Mount the fixture onto the mounting plate and secure it in place by reinstalling the knurled nuts.
2. Align the pins on the fixture to the holes on the shade.
3. Reinstall the shade by pushing it into the fixture until secure.